



Brand: Ricoh
Ikon Code: IK07163
OEM Ref #: MP4054SP Fuser Unit/110V
For Use in:
 Ricoh MP4054SP/4055SP/5054SP/5055SP/
 Ricoh MP6054SP/6055SP



Brand: Ricoh
Ikon Code: IK07164
OEM Ref #: MP4054SP Fuser Unit/220V
For Use in:
 Ricoh MP4054SP/4055SP/5054SP/5055SP/
 Ricoh MP6054SP/6055SP



Brand: Ricoh
Ikon Code: IK07159
OEM Ref #: AB01-2096/AB01-2116
For Use in:
 Aficio MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Lanier MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Savin MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Ricoh MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Lanier MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Savin MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Ricoh MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 Lanier MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 Savin MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 IM C2000/C2500/C3000/C3500/C4500/C5500/C6000/
 Lanier IM C2000/C2500/C3000/C3500/C4500/C5500/C6000/
 Savin IM C2000/C2500/C3000/C3500/C4500/C5500/C6000



Brand: Ricoh
Ikon Code: IK07160
OEM Ref #: AB01-2117/AB01-2120
For Use in:
 Aficio MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Lanier MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Savin MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Ricoh MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Lanier MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Savin MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Ricoh MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 Lanier MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 Savin MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 IM C2000/C2500/C3000/C3500/C4500/C5500/C6000/
 Lanier IM C2000/C2500/C3000/C3500/C4500/C5500/C6000/
 Savin IM C2000/C2500/C3000/C3500/C4500/C5500/C6000



Brand: Ricoh
Ikon Code: IK07161
OEM Ref #: AB01-2118
For Use in:
 Aficio MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Lanier MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Savin MPC2003/C2503/C2004/C2504/C2004ex/C2504ex/
 Ricoh MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Lanier MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Savin MPC3003/C3503/C3004/C3504/C3004ex/C3504ex/
 Ricoh MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 Lanier MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 Savin MPC4503/C4504/C4504ex/C5503/C6003/C6004/C6004ex/
 IM C2000/C2500/C3000/C3500/C4500/C5500/C6000/
 Lanier IM C2000/C2500/C3000/C3500/C4500/C5500/C6000/
 Savin IM C2000/C2500/C3000/C3500/C4500/C5500/C6000

